





Rocker Panel Brush [21in Brush]

RB1





Rocker Panel Brush [21in Brush] - RB1





Rocker Panel Brush [21in Brush] - RB1


Parts List		
PART NUMBER	QTY	DESCRIPTION
RB1A	1	Driver Side Rocker Panel [Hydraulic]
RB1B	1	Passenger Side Rocker Panel [Hydraulic]
RB1AM-21-12 EL	2	21" Brush Assembly [EL]





Driver Side Rocker Panel [Hydraulic] - RB1A


Parts List		
PART NUMBER	QTY	DESCRIPTION
CB1ADAS	1	AVW Style Rocker Sleeve
FW12	4	1/2" Flat Washer
HN1213	4	1/2" - 13 UNC Hex Nut
RB1AA	1	24" Rocker Leg
RB1ADX36	1	Empty Rocker Arm
RB1AF	1	Shock Absorber Assembly
RB1LPA	1	Hyd.Tube Assembly [Rocker]
RB2AB	1	Arm Mount Assembly [Driver][Hydraulic]
UB - SQ050X400X425X1950	2	Square U Bolt D 1/2" x 4 1/2" x 4 1/4" LG
WA2GA	1	Front Shock Mount
RB2AEA	1	Brush Drive Upper Assembly [H]





Passenger Side Rocker Panel [Hydraulic] - RB1B


Parts List		
PART NUMBER	QTY	DESCRIPTION
CB1ADAS	1	AVW Style Rocker Sleeve
FW12	4	1/2" Flat Washer
HN1213	4	1/2" - 13 UNC Hex Nut
RB1AA	1	24" Rocker Leg
RB1ADX36	1	Empty Rocker Arm
RB1AF	1	Shock Absorber Assembly
RB1LPA	1	Hyd.Tube Assembly [Rocker]
RB2BB	1	Arm Mount Assembly [Passenger][Hydraulic]
UB - SQ050X400X425X1950	2	Square U Bolt D 1/2" x 4 1/2" x 4 1/4" LG
WA2GA	1	Front Shock Mount
RB2AEA	1	Brush Drive Upper Assembly [H]






Arm Mount Assembly [Driver] - RB2AB

Parts List		
PART NUMBER	QTY	DESCRIPTION
BRG-RB1WB-TB1WC-SS	2	1-1/4" Pillow Block
FW12	10	1/2" Flat Washer
HHCS1213150	2	1/2"-13 x 1 1/2" L Hex Screw
HHCS1213200	4	1/2"-13 x 2" L Hex Screw
HHCS3816075	1	3/8" - 16 x 3/4" Hex Screw
HHCS3816150	4	3/8"-16 UNC x 1 1/2" Hex Screw
HHJN3816	1	3/8"-16 Heavy Hex Jam Nut
HN1213	6	1/2-13 Hex Nut
RB1ABAM	1	Moveable Rear Shock Mount
RB1AC-2021	1	Bumper Assembly
RB1ABA	1	Arm Mount Base Plate Assembly [Driver]
RB1RHLH	1	Removable Hydraulic Line Holder
SLW12	6	1/2" Split Lock Washer



ISO View [Front]




ISO View [Back]




Arm Mount Assembly [Passenger] - RB2BB

Parts List		
PART NUMBER	QTY	DESCRIPTION
BRG-RB1WB-TB1WC-SS	2	1-1/4" Pillow Block
FW12	10	1/2" Flat Washer
HHCS1213150	2	1/2"-13 x 1 1/2" L Hex Screw
HHCS1213200	4	1/2"-13 x 2" L Hex Screw
HHCS3816075	1	3/8" - 16 x 3/4" Hex Screw
HHCS3816150	4	3/8"-16 UNC x 1 1/2" Hex Screw
HHJN3816	1	3/8"-16 Heavy Hex Jam Nut
HN1213	6	1/2-13 Hex Nut
RB1ABAM	1	Moveable Rear Shock Mount
RB1AC-2021	1	Bumper Assembly
RB1BBA	1	Arm Mount Base Plate Assembly [Passenger]
RB1RHLH	1	Removable Hydraulic Line Holder
SLW12	6	1/2" Split Lock Washer






BRUSH DRIVE UPPER ASSEMBLY [H] - RB2AEA



Parts List		
PART NUMBER	QTY	DESCRIPTION
EL90STL050JIC050NPT	2	Elbow (1/2" NPT Male X 1/2" JIC Male)
SLW12	8	1/2" Split Lock Washer
TB0080-TB1ADBM	1	Hydraulic Motor
HN1213	8	1/2-13 Hex Nut
RB1AEA-EL	1	Rocker Motor Mount [EL]
MM5E	1	Hydraulic Motor Mount Adaptor plate
HHCS3816100	4	3/8" - 16 x 1" UNC Hex Screw
RB2AEB-P1-1-0106	1	Brush Connecting Disc
HHS1420150	3	1/4"-20 x 1.5" LG. Hex Screw
SLW14	3	1/4" Split Lock Washer
HHCS3816125	4	3/8"-16x1 1/4" UNC Hex Screw
SLW38	4	3/8" Split Lock Washer
HN3816	4	Hex Nut - 3/8"-16
FW38	4	3/8" Flat Washer
TRSS05013x0400	4	Threaded Rod 1/2"-13 x 4" LG.
STB-P1X100	1	1" Split Taper Bushing





Brush Assembly - RB1AM-21-12EL

Parts List		
PART NUMBER	QTY	DESCRIPTION
RB1AMA-21-10	28	Cloth 12x23.5x25
RB1AMC-21-12EL	1	BRUSH CORE 21" [EL]

